

DECO-POST INGROUND INSTALL



1. Dig Holes. Measure out the desired post centers and dig post holes. Holes should be a minimum of 150mm in diameter and 600mm deep for a 1800h post.

2. Cut Post. Remove the cover pieces as required and measure and cut the core part of the post to the desired height.

3. Concrete. Concrete the core part of the post into the ground, ensuring it is level and plumb. DO NOT USE RAPID OR QUICK SET CONCRETE. Follow the manufacturers instructions. Leave to set.

4. Fix Panels. Insert decorative panels into desired post channels. Fix panels using self-drilling metal screws through the fixing points indicated (4A / 4B).

5. Replace covers. (a) Measure and cut the cover pieces to suit the finished post height. (b) Snap into place and (c) insert end-caps to finish.

WARNING
DO NOT USE RAPID OR
QUICK SET CONCRETE
AS IT WILL CORRODE
THE POST