



DECO POST BASE PLATE INSTALL



Deco Post Base Plates are available through CSO, they are a stocked Special order product.



1. Remove end-caps and infill, measure and cut the post to size
2. Remove the large Clip-on cover strip and cut gomm off one end. Keep both Pieces



3. Clip on the short gomm piece to the bottom of the post
4. Using the screws provided with the base plate fix the base plate to the post.
 - a. Make sure the countersunk part of the base plate is facing out
 - b. Use an impact driver at a low speed
 - c. The screw will push the small piece away before drawing it back up



5. Fix your base plate down to the ground using appropriate fixings for your surface
6. Fix your screens in place using the usual method.
7. Clip on the rest of the cover plate and replace endcaps and infill as necessary.